


H33013

Diagram 2



Side, tail & number plate lights


- 16 RH rear light unit
- a = tail light
- b = stop light
- c = reversing light
- 17 High level stop light
- 18 Stop light switch
- 19 Reversing light switch

- 11 Combination switch
- a = direction indicators/
- 12 LH headlight unit
- a = sidelight
- 13 RH headlight unit
- a = sidelight
- 14 Number plate light
- 15 LH rear light unit
- a = tail light
- b = stop light


Key to items

- 1 Battery
- 2 Starter motor
- 3 Alternator
- 4 Ignition switch
- 5 Battery fusebox
- 6 Passenger fusebox
- 7 Engine cooling fan
- 8 Engine cooling fan switch
- 9 Starter inhibitor relay (auto.)
- 10 Light switch
- a = side/headlight switch

- Ws White
- Bl Blue
- Ge Yellow
- Ro Red
- Br Brown
- Gr Grey
- Ll Lilac
- Sw Black



Stop & reversing lights



Starting, charging & engine cooling fan